

2-Man Deadly Duck Blind

Shown right out of the box.
Separate the panels and assemble the hinges, latches and latch onto the panels, per the additional sheet.
Two **10mm wrenches** and/or ratchet are needed.

AeroOutdoors.com[®]

← Products Targeted for Success →

316 East "B" Circle · Pasco, WA · 99301

(509) 545-8000



A finished blind is shown to R.
The door is shown open.
Notice the extra EZ-FAB mesh to camo the blind frame. Leave some overlap, but trim where there is interference.
There are pre-cut pieces & zip ties included for the ends.

Decision: For 2-Man stand-a-alone, fabricate both ends the same, with the center strut. The strut on the non-door ends assists in maintaining the shape of the end during transport.

Camo the blind: Add knotted mats to the top panel above the heads, and then add natural materials to all other sides/top.



OPTION 1:

Shown to the Right is the end panel layout before assembly.

There are 2 plates on front and back, for both the top and the bottom of the vertical strut.

There are also 2 sizes of plates.

The larger ones are on the bottom.

Use the nuts and bolts provided.

Attach the door, on the chosen end.

Assemble the parts; add the EZ-FAB mesh with zip ties so that it is taught, but not stretched. Allow some give to weave natural materials into.



OPTION 2: Shown to the Right is the end configuration chosen to allow a pass through from one blind to another.

4-Man Blind: Place 2 blinds together, with the doors installed on opposite ends. Then the other sides go together, allowing free passage between the blinds.

6-Man Blind: Assemble 2 blinds per above instructions. On the third, used for center blind, there will be no doors or vertical struts. Additional L brackets will be needed for one side.

Contact Aero for purchase.

